





S. A. Asher, Department of Chemistry

TEM of Polystyrene Spheres 300 nm (QLS)






A




B



A) Polymerized crystalline colloidal array (PCCA)

B) Photograph of typical PCCA showing bright iridescence.


C



C) As the hydrogels shrink and swell, the lattice spacing of the CCA locked within changes as well. Thus, the volume changes of the gel can be observed by monitoring the change in diffraction.

FREE ENERGY CONTRIBUTIONS TO GEL VOLUME


$$G_{\text{tot}} = G_{\text{mix}} + G_{\text{ion}} + G_{\text{elas}}$$



Poly(N-isopropylacrylamide) : The Driving Force


(PNIPAM) undergoes a reversible phase transition when heated above 32.1 °C. This coil-globule transition is analogous to a liquid-vapor phase transition. The recipe and synthesis conditions determine the extent of volume changes and whether they are continuous or discontinuous.

Chemical Structure of NIPAM






S. A. Asher, Department of Chemistry





S. A. Asher, Department of Chemistry




**Wavelength selective reflector tuned
across the visible spectrum**

S. A. Asher, Department of Chemistry



Diffracting Materials for Chemical Sensing




- Polystyrene colloid.
- Side group capable of molecular recognition.
- ★ Substrate to be recognized.
- ↔ Hydrogel matrix.




S. A. Asher, Department of Chemistry

We constructed cation and anion sensors by attaching chelating agents to the PCCA. Chelation of the analyte ion results in immobilization of the counterion which results in an osmotic pressure which swells the gel and red shifts the diffraction in proportion to the analyte concentration.






S. A. Asher, Department of Chemistry









S. A. Asher, Department of Chemistry





S. A. Asher, Department of Chemistry


Glucose Oxidase Reaction Mechanism






S. A. Asher, Department of Chemistry

1-(3-Dimethylaminopropyl)-3-ethylcarbodiimide



5-(Biotinamido)pentylamine




+ avidinated enzyme






S. A. Asher, Department of Chemistry



Gel Particulate Colorimetric Reagent






S. A. Asher, Department of Chemistry

Chemical (glucose) Sensing Fantasies



Fig. 1 Concept for glucose sensing device for tear fluid and for implants. The color diffracted defines the glucose concentration.



GlucoviewTM
Ocular Insert

GlucoviewTM
Diagnostic Contact Lens



GlucoviewTM
Subcutaneous Insert



S. A. Asher, Department of Chemistry




PCCA Sensing Array for Glucose, pH, Recreational Pharmaceuticals and Alcohol, Stress Hormones, etc.



Subcutaneous Sensors

Remote Sensing



Collaborators:

Professor Rob Coalson
Professor Ajay Sood
Dr. Rasu Kesavamoorthy
Professor Craig Wilcox

University of Pittsburgh
Indian Institute of Science
Indira Gandhi Centre for Atomic Research
University of Pittsburgh

Graduate Students:

Dr. Paul Rundquist
Dr. Perry Flaugh
Dr. Jim Conners
Charles Brnardic
Zhijun Wu
Dr. John Holtz
Guisheng Pan
Dr. Lei Liu
Jesse Weissman
Hua Zhang
Jonathan Keim
Marta Kamenjicki
Michael Baltusavich
Chad Reese

Eastman Chemical
Sun Oil
Institute of Paper Chemistry
Eli Lilly
Monsanto
Katz School of Business
Colgate Palmolive
PraxAir
UniLever

Post Docs:


Dr. Sesh Jagannathan
Dr. Panos Photinos
Dr. Song-Yuan Chang
Dr. Albert Tse
Dr. Hari Sunkara
Dr. Calum Munro
Kangtaek Lee
Wei Wang
Igor Lednev
Ying Wang
Serban Peteu
Xu Xiangling

Eastman Kodak
S. Oregon State University
EM Industries
Reichhold Chemical
DuPont
PPG Industries, Inc.
Inje University, Korea

Funding:

ARMY
ONR
DARPA

NSF
NIH



Hierarchically Assembled Intelligent Materials for Chemical Sensing and Electro-optics

Asher Research Group, University of Pittsburgh

Macromolecules




Mesoscopic



Nanoscopic




Molecules




Molecular Recognition

Photonic and Magnetic Quantum Dots



Photochromics

Colloidal Particles



Quantum Dots

Responsive Materials For

Chemical Sensing Applications

- In vivo Clinical Sensors
- Point of Care Sensors
- Environmental Sensors
- Biological and Chemical Agents
- Remote Atmospheric Sensing

- Optical Limiters and Switches
- Chemical Sensors
- Optical Memory
- Magneto – Optical Transducers

Optical Materials

- Optical Limiters for eye and sensor Protection
- Photonic Materials for Optical Switching and Memory
- Display Device Applications

Application of Nanoscience for Chemical Sensing

Science (2000) **289**: 1757

Scanometric DNA Array Detection with Nanoparticle Probes

T.A. Taton, **C.A. Mirkin**, and R.L. Letsinger
Northwestern University, Evanston, IL

Science (2000) **287**: 622

Nanotube Molecular Wires as Chemical Sensors

J. Kong, N.R. Franklin, C. Zhou, M.G. Chapline, S. Peng, K. Cho, **H. Dai**
Stanford University, Stanford, CA 94305

Science (1997) **278**: 840

A Porous Silicon-Based Optical Interferometric Biosensor

V.S.-Y. Lin, K. Motesharei, K.-P.S. Dancil, **M.J. Sailor**, M.R. Ghadiri
University of California, San Diego, La Jolla, CA
The Scripps Research Institute, La Jolla, CA

Science (2001) **291**: 443

NANOMATERIALS: Stretching the Mold

T.E. Mallouk

Pennsylvania State University, University Park, PA

J.Am. Chem. Soc. (1997) **119**: 11306


Diffusion-Limited Size-Selective Ion Sensing Based on SAM-Supported Peptide Nanotubes

(SAM – Self-assembled monolayers)

K. Motesharei and M.R. Ghadiri
The Scripps Research Institute, La Jolla, CA


Nanosynthesis for Materials Development

Nanosynthesis can fill a gap in our capabilities.



Nanosynthesis for Materials Development

Current status in production according to scale.



The goal of this subproject is to fill in the middle.



S. A. Asher, Department of Chemistry

Periodic Table of the Elements

s-block

1	New Designation
IA	Original Designation

s-block

1	H	2
1.0094		IIA

s-block

3	4	Be
Li	9.0122	

d-block

3	4	5	6	7	8	9	10	11	12	
Na	Mg	Sc	Ti	V	Cr	Mn	Fe	Co	Ni	Cu
22.990	24.305	44.956	47.88	50.942	51.996	54.938	55.847	58.933	58.69	63.546
K	Ca	Y	Zr	Nb	Mo	Tc	Ru	Rh	Pd	Ag
39.098	40.08	88.906	91.224	92.906	95.94	(98)	101.07	102.91	106.42	107.87
Rb	Sr	39	40	41	42	43	44	45	46	47
85.468	87.62	178.49	180.95	183.85	186.21	190.2	192.22	195.08	196.97	200.59
Cs	Ba	56	57	72	73	74	75	76	77	78
132.91	137.33	178.49	180.95	183.85	186.21	190.2	192.22	195.08	196.97	204.38
Fr	Ra	87	88	89	104	105	106	107	108	109
(223)	(226.03)	(261)	(262)	(263)	(262)	(265)	(266)	(267)	(265)	(267)

Non-Metals

13	14	15	16	17
III A	IV A	V A	VI A	VII A
B	C	N	O	F
10.81	12.011	14.007	15.999	18.998
Al	Si	P	S	Cl
26.982	28.086	30.974	32.06	35.453
Ga	Ge	As	Se	Br
69.72	72.59	74.922	78.96	79.904
In	Sn	Sb	Te	Kr
114.82	118.71	121.75	127.60	83.80
Tl	Pb	Bi	Po	Xe
204.38	207.2	208.98	(209)	131.29

p-block

18	VIIIA
He	4.00260

Metals

isotopes.)	Phases
	Solid
	Liquid
	Gas

Rare Earth Elements

57	d-block	f-block
La		
138.91		
Ce	58	59
140.12	Pr	Nd
140.91	144.24	141.96
144.24	(145)	150.36
Pm	60	61
141.96	Sm	Eu
150.36	163	164
151.96	Gd	Tb
157.25	165	166
158.93	Tb	Dy
162.50	167	Ho
164.93	168	Er
167.26	169	Tm
168.93	170	Yb
173.04	171	Lu
174.97		

Lanthanide Series

89	Ac	90	Th	91	Pa	92	U	93	Np	94	Pu	95	Am	96	Cm	97	Bk	98	Cf	99	Es	100	Fm	101	Md	102	No	103	
227.03	(227.03)	232.04	(231.04)	238.03	(237.05)	(244)	(243)	(247)	(251)	(252)	(257)	(258)	(259)	(260)															

Actinide Series

From Hyper Chemistry on the Web! <http://library.thinkquest.org/2690/ptable/ptable.html>




C. Wilcox, Department of Chemistry


Nanotech: Process and Materials Development

The “Diatomeric Molecule” of Nanosynthesis.

Chemical
synthesis




Nano
synthesis



Rational control of microsphere assembly.



Nanosynthesis for Materials Development



What do we need to succeed?

Anisotropic building blocks. (atoms, molecules)
Bonding strategies - nanoadhesives. (bonding)
Techniques for handling - dispersion. (solvation)
Separation and purification methods

Payoff: Unlimited capacity to prepare mesoscale structures.

S. A. Asher, Department of Chemistry



Crystalline Colloidal Self-Assembly:

MOTIF

FOR

CREATING SUBMICRON

PERIODIC SMART MATERIALS



S. A. Asher, Department of Chemistry

**CRYSTALLINE COLLOIDAL ARRAYS
CONTAINING MOLECULAR RECOGNITION
AGENTS: CHEMICAL SENSING MATERIALS**

A MOTIF FOR SENSING

ALL, MANY, SOME, A FEW


CHEMICAL SPECIES



S. A. Asher, Department of Chemistry

Mesoscopically Periodic Materials

CCA




Self-Assembling
Diffracting
Structure

Fragile

Optical Filters

PCCA



Hydrogel
Volume
Phase
Transition

Robust


Tunable
Spacings

Optical Filters

NLO Switches

Optical Limiters

SCCA



Rigid 3-D
Periodic
Materials


Rugged

Optical Filters

NLO Switches

Optical Limiters

IPCCA



Electronically
Chemically
Thermally
Responsive
Materials
Smart
Materials

Agile Optical
Filters

Chemical
Sensing


Display
Devices




S. A. Asher, Department of Chemistry

Crystalline Colloidal Arrays

1. Fabricated From Colloidal Particles




2. Particles Self Assemble Into 3-D Ordered Crystal Structure





S. A. Asher, Department of Chemistry

For 10^{13} spheres/cc \iff Crystalline Colloidal Array




Spacings only depend upon the Particle Number Density and Crystal Structure.

**Bragg Diffraction occurs with Phenomenal Efficiency
Transmittance $< 10^{-8}$ for 0.5 mm Thickness**

- **Dynamical Diffraction Limit**

Introduction





S. A. Asher, Department of Chemistry

